

# Remote Data Transfer Settings for GSI Equipment

- When transferring data, make sure to first hit the “REMOTE” button on the keypad of the unit, “Remote” will appear on the display and should remain on as long as unit is powered ON.
- On GSI Tymptstar, press “ETF” button, then “RETURN” button.
  - Select “INSTRUMENT OPTIONS” softkey
  - Select “DATA TRANSFER SETTINGS” softkey
  - For “Tymp” change setting to “SUMMARY + GRAPHICS”
  - Select “STORE”